GE Measurement & Control

# phoenix datos|x

Advanced CT software for fully automated data acquisition, reconstruction and volume processing with GE's industrial CT systems

# Key features & benefits

- Up to 14 times faster volume reconstruction for accelerated sample throughput
- Improved automatization functions for highly effective system usage
- CT system performance monitoring following ASTM 1695 guideline
- click & measure|CT functionality for high throughput automated batch CT inspection task execution
- Production mode with one-button CT functionality and intuitive user interface for improved ease of use
- Supports optional metrology|edition CT system configuration for high precision 3D measurements following VDI 2630 guideline



Workflow optimization for production CT tasks



With phoenix datos x software, the entire CT process chain can be fully automated. This minimizes operator time and influence, while highly increasing the throughput as well as the repeatability and reproducibility of CT results. 3D failure analysis or 3D metrology tasks like generation of first article inspection reports by 3rd party software products can be executed automatically. datos x offers also an expert mode for flexible laboratory and research tasks with optimized CT results.

# Workflow optimization for production CT tasks

1. Identify part e.g. barcode 2. Initiate CT scan process

3. Acquire and process CT data

4. Verify analysis results









# Automated acquisition with one-button CT

### Production mode with highly simplified user interface

• Improved intuitive graphical user interface for easy usage, a fast learning curve and integrated control of the system (X-ray tube, detector, sample manipulator) for setup and start of high quality CT scans

• Process flow orientated function tool bar for step-by-step workflow setup with intuitive user interface

### Support of up to five different user levels

- Password protected user management
- Operator mode: basic features ensures running the system for industrial analysis and metrology tasks with a minimum of user training

• Expert and admin mode: full access to all available functions and parameters for extremely flexible use of the system for scientific research and programming of quality analysis tasks.

### Automated system calibration functions

System preparation for CT scan (detector calibration, tube conditioning etc.)

### Semi-automated system performance test following ASTM 1695

- New datos|x function for quantitative CT image performance monitoring
- Determination of modular transfer function (spatial resolution) in lp/mm per ASTM 1695
- $\bullet$  Determination of contrast discrimination function (contrast sensitivity, inverse of CNR) in %
- Includes report generation



Scan startup dialog					
Part data					
Serial number:	9876543	987654321			
Part type:	PT123				
Project path:	s:\CT_DA	TA\987654321\987654321_PT123pca			
Additional information					
Item		Value			
Component Name Component ID		xxx 1234			
		START SCAN			





Measurement of sphere distances with a calibrated test specimen and comparison to the calibrated values

### **Batch functionality**

For automated execution of pre-defined inspection tasks with click & measure|CT enlarges the degree of system usage of up to 20-30%

• **"click & measure|CT"** functionality: from scan start to displaying and analysis of the 3D results on the screen without manual user interaction in just 3 steps:

- 1) Insert the work piece
- 2) Start the scan
- 3) Check results

• **Complete automation** of the full CT data handling chain (system calibration e.g. tube & detector), data acquisition, volume reconstruction / optimization and CT data processing for pre-defined standard tasks.

• Automated multi-object scans: Scan, reconstruct and process different objects with different parameters with just one setup and no further interaction

• Automated procedures for metrology, e.g. voxel/calib for high precision determination of FOD/FDD







# Automated reconstruction and analysis

- Multi GPU based volume reconstruction using velo|CT for up to 14× faster CT results for accelerated sample throughput without any reconstruction PC cluster required
- **multivolume** reconstruction for ultra large volume data sets which exceed physical memory
- Clear display of CT results: volume visualization in 2D axis views and 3D render mode
- **Reproducible high-resolution CT results** even by unskilled operators after minimal training
- Wide spectrum of modules for ease of use and accurate CT results
- Diverse **automatic volume optimization functions** (e.g. filter functions for noise reduction, ring artifact reduction)
- Automatic generation of **first-article-inspection reports** in < 1 hour possible
- **Interface** to various external software packages for further automatic volume processing (e.g. VGStudio MAX, VSG Avizo, PolyWorks and others) and execution of pre-defined 3D evaluation macros
- DICONDE CT data export compliant to the international standard







#### Modules and module packages

Proprietary datos x CT acquisition and reconstruction software including:

click & measure|CT
 for completely automated CT process chain including production mode

#### datos x module package "basic":

- agc|module
   automated geometry calibration
- bhc+|module
   beam hardening correction, automated for one-material samples
- rar|module
   automated ring artifact reduction
- auto|roi
   automated determination of reconstruction volume

#### datos x module package "advanced" in addition to the "basic" package:

- scan|optimiser optimization of scans with linear drift effects
- multilscan automated acq./rec. of multiscans
- mv/reco
   automated piecewise reconstruction of large volumes
- sector|scan region of interest scans (roi|scan)
- fast|scan
   CT scans with continuous sample rotation

**Opt. 3D metrology bundle:** High accuracy direct measuring system, 2 calibration objects, phoenix datos|x CT software package "metrology"

#### datos x module package "metrology":

	1 1 3	57
٠	surface extraction	automated generation of surface data
•	easy calib	module for CT system calibration
	initia de la tratación de la companya de la company	a 11 11 1 1 1 1 1 1 1 1 1 1 1

calibration|object 1 calibration tool with certificate

#### datos|x module package "click & measure|CT":

<ul> <li>auto CT &amp; batch CT</li> </ul>	for completely automated CT process chain (e.g. aquisition, reconstruction, execution of
	modules for data optimization, surface extraction, link to e.g. VGStudio MAX or Avizo,
	execution of measurement templates)
<ul> <li>one-button CT</li> </ul>	for efficient and simple CT operation (production mode)
<ul> <li>ext launch</li> </ul>	module for execution of external software packages using CMD, JavaScript or python
<ul> <li>DICONDE export</li> </ul>	CT data export in international DICONDE standard format

# Additional modulesvelolCT

Additio	
<ul> <li>velo</li> </ul>	

multi|volume

Multi-GPU based reconstruction acceleration for CT results within just a few seconds or minutes, depending on the volume size. Versions: "basic", "speed" and "highspeed" for up to 14 x faster processing than current reconstruction solution reconstruction for ultra large volume data sets which exceed physical memory

# phoenix datos x - your benefits

- CLEAR: highly improved interface for ease of use and intuitive process flow
- EFFICIENT: ultra fast volume reconstruction and decreased CT operator time
- AUTOMATIC: one-button CT batch processing tools for data acquisition, volume reconstruction and 3D analysis
- FLEXIBLE: functionality and interfaces for customized CT solutions
- EASY: significant reduction of required training and operator time

ee 86
----------

GE Sensing & Inspection Technologies GmbH phoenix|x-ray Niels-Bohr-Str. 7 31515 Wunstorf Germany Tel.: +49 5031 172 0 Fax: +49 5031 172 299 E-mail: phoenix-info@ge.com **GE Inspection Technologies, LP** 50 Industrial Park Rd Lewistown, PA 17044, USA Tel.: +1 717 242 03 27 Fax: +1 717 242 26 06 E-mail: phoenix-usa@ge.com



## www.ge-mcs.com/phoenix

© 2014 General Electric Company. All rights reserved. Specifications are subject to change without notice. GE is a registered trademark of General Electric Company. Other company or product names mentioned in this document may be trademarks or registered trademarks of their respective companies, which are not affiliated with GE. nanotom® customer image courtesy of Zebicon, Billund, Denmark; aluminum cylinder head courtesy of ACTech Engineering, Freiberg/Saxony, Germany.



